



## SAFE WORK PROCEDURES

1. Raise work permit before start of work like General work permit, Height work permit or Hot work permit whichever is applicable.
2. Conduct tool box talk meeting with all concern employees.
3. Refer activity SOP is applicable before start of work.
4. Wear applicable PPEs like Safety Helmets, Safety shoes, Safety goggles, Safety aprons, Hand gloves etc.
5. Apply loto to the equipment.
6. Put barrier tape to the area / working cell.
7. Use standard ISI mark tested tools
8. Use Fire bucket / FE near hot work area.
9. Use tested ladder for height work.
10. Use safety belt with hooked up while working at height..