

NEXVITECH INDIA PVT. LTD.

Work Permit System

1) Pre-Job Checks/Pre-Inspection required before issuing Work Permit System.

- Description of work to be carried out.
- Description of plant and location.
- Identify hazards and assess risks.
- Identification of controls.
- Additional permits, e.g. hot work.
- Isolation of services.(e.g.Cut off the Power supply)
- PPE/ Special PPEs.
- Emergency procedures.

2) handover of permit: Workers/Contractor sign to say they accept controls or receive the permit from issuer.

3) After receiving the Permit, Work can now start and plant is now under the control of the workers/contractors (receiver).

4) After completion of work, Contractors/ Workers sign o permit to say that they have left the workplace in as condition, work is complete and operations can resume.

5) The permit will be returned to Issuer.

6) The authorised person / permit issuer accepts plant/sit back and can remove isolations, etc. Cancels permit.

7) Plant is now returned to the control of the "site/". (Certifying work tested and plant satisfactorily recommissioned.)