

ONKAR ENGINEERING WORKS

GUT NO-34, PLOT NO-35, BEHIND K-87(SAVERA AUTO COMPS), MIDC, WALUJ, AURANGABAD
 EMAIL ID - info@onkarengineeringworks.co.in/mdhimate99@gmail.com, MOB NO - 9823067732/9172203032

METHOD STATEMENT

Work	Sr No	Activity	Responsibility
HDPE/PP/PVC PIPELINE	1	Inspection of work and work location	Supervisor
	2	Understanding the Application of work	Supervisor
	3	Ensuring if the site safe for working/if not apply control measures	Supervisor
	4	Checking Material Availability/ if not then order	Supervisor
	5	Explaining the work to workers	Supervisor
	6	Taking the measurement for Pipeline	Worker
	7	Cutting Pipe	Worker
	8	Heating the Mirror/Applying Solvent	Worker
	9	Joining the Pipe and fitting	Worker
	10	Cooling the Mirror	Worker
	11	Cleaning the Work Location of wastage material	Worker
	12	Testing the Pipeline	Worker
	13	Keeping the tools at their designated places	Worker
	14	Washing Hands	Worker
FRP LINING	1	Inspection of work and work location	Supervisor
	2	Understanding the Application of work	Supervisor
	3	Ensuring if the site safe for working/if not apply control measures	Supervisor
	4	Checking Material Availability/ if not then order	Supervisor
	5	Explaining the work to workers	Supervisor
	6	Taking measurement of Area	Worker
	7	Cutting the Emulsion Mat	Worker
	8	Taking required Resin in a Container	Worker
	9	Adding Hardner into resin	Worker
	10	Mixing Well with brush	Worker
	11	Applying Emulsion Mat on Surface with resin by brush	Worker
	12	Checking if FRP is Hardening after 0.5 to 1.5 hours	Worker
	13	Spark Testing (if required)	Worker
	14	Cleaning the brush	Worker
	15	Cleaning the work location of wastage material	Worker
	16	Keeping Remaining material at designated Place	Worker
	17	Washing Hands	Worker
WORKING AT HEIGHT	1	Checking if Ladder/ Structure is strong and can sustain weight	Worker
	2	Wearing Safety Belt/Helmet	Worker
	3	Lock both hooks	Worker
	4	Climb with 2 hooks locked	Worker
	5	If structure is not available for locking hooks then use wire rope	Worker
		for plugging safety belt. Tie Wire rope to a rigid support	Worker
WORKING WITH CHEMICALS	1	Always use rubber hand gloves and Goggles	Worker
	2	Do not Inhale the chemical fumes	Worker
	3	Keep chemical away from direct contact of skin	Worker