

WORK PROCEUDER

1. TAKE PERMIT BY AUTHROIZED PERSON
2. SITE VISIT WITH OUTHORISED PERSON OF ETL
3. SAFETY TRAINING ON SITE BY OUTHORISED PERSON OF ETL
4. BARRICATE AREA.
5. EXCAVATION, SOLLING, PCC, RCC
6. CLEAN THE WORKING AREA/PLACE.
7. CLOSE THE WORK PERMIT.

Civil-Tech Conpro



Scanned with CamScanner