

Ref.

Date 20/06/23

Work Permit System

We M/s A.N.S. ENTERPRISES Generally use 2 types of permit are as follows.

1. Height Work
2. General Work

Procedure to complete the work permit is as follows,

1. Mention date and time of work to be done
2. Mention department of work to be done
3. Correct information of worker to be present at the time of work
4. Verification from user department
5. Confirmation from Area HOD
6. Signature from HR after verification of CSM
7. Signature from Plant Head/Operation Head
8. Closure of W/P from the user department after completion of work assigned.

For A.N.S. ENTERPRISES.

mahesh sahani

