

## Shil Technologies Pvt.Ltd

### Hazard Identification And Risk Assesment

Type Of Work	Risk	Control Measures
Dencification Floor, Grinding Floor, Grovting Floor, Chemicals works.	<p>Dust Raised by the Dencification Work</p> <p>Noise And Vibration caused by the machines , hand -tools, explosives, and falling /colapsingbparts of the building. falling objects</p> <p>hand injury is a risk where camicals works</p> <p>foot injury is a risk where grinding &amp; chemicals work</p>	<p>Clearly marking and with barriers or hordings any debris and dust will be removed as soon as possible to a safe place, and workplaces as well as pathways kept tidy.</p> <p>Ensuring machines and equipment are maintained properlyand regularly.</p> <p>use of hand gloges</p> <p>Use of shafety Shose and Helmet</p>
Excavation	<p>Excavated soil Or Equipment falling on worker.</p> <p>moving machinery near the edge of the excavation ca n cause a collapse.</p> <p>The accidental severing of underground utility lines/ power lines.</p>	<p>Correct desingning v of sloping and benchnig systems</p> <p>correct designing of support systems, shield systems, and other protective systems plusa ppropriate handling opf material and equipment plus</p> <p>attention to correct installation and removal of equals protection or employee at excavations use of safety helmet</p> <p>protectingb hand and eyes by safety helmet and glasses.</p>