

BEFORE

AFTER

PACKING STD														FMT NO.	SPSR/POD
														EFF. DATE	01.04.2023
														REV. NO.	00
S.NO.	PART NAME	MODEL NO	CUSTOMER NAME	OUTER PACKING DETAILS										Total quantity (A+B+C) (As/Inch) / QTY.	Weight per box Bin
				corrugated box			Plastic bin		Wooden Box						
				Poly type/Tk	Poly bag size (inch)	Quantity per poly bag (A)	Bin size	No. of poly bags/bin (B)	No. Of Poly Type of Cont. Bag.	Bin size (inch)	No. of poly bags/bin (C)	Bin size	No of corrugated box/wooden box (D)		
1	SEAT PIPE	J1A, J1C, J1D	ENDURANCE	A4	A4	1001	E08	1	1	NA	1	NA	NA	100	
Pictorial View (Inner Packing)				Pictorial View (Outer Packing)				Pictorial View (Finished Good)							
Supplier				Customer											
Prepared By: Miss shalu				Prepared By:											
Approved By: Mr. Ashish singh				Approved By:											

PACKING STD														FMT NO.	SPSR/POD
														EFF. DATE	13.08.2024
														REV. NO.	01
S.NO.	PART NAME	MODEL NO	CUSTOMER NAME	OUTER PACKING DETAILS										Total quantity (A+B+C) (As/Inch) / QTY.	Weight per box Bin
				corrugated box			Plastic bin		Wooden Box						
				Poly type/Tk	Poly bag size (inch)	Quantity per poly bag (A)	Bin size	No. of poly bags/bin (B)	No. Of Poly Type of Cont. Bag.	Bin size (inch)	No. of poly bags/bin (C)	Bin size	No of corrugated box/wooden box (D)		
1	SEAT PIPE	J1A, J1C, J1D	ENDURANCE	A4	A4	1001	E08	1	1	NA	1	NA	NA	100	
Pictorial View (Inner Packing)				Pictorial View (Outer Packing)				Pictorial View (Finished Good)							
Supplier				Customer											
Prepared By: Miss shalu				Prepared By:											
Approved By: Mr. Ashish singh				Approved By:											

NOTE :- पैकिंग करने समय हमें यह ध्यान रखना है की J1D के अंदर एक ब्रू आइसोलेशन सॉल्वे होना चाहिए और J1C के अंदर दो ब्रू ब्रू आइसोलेशन सॉल्वे होना चाहिए और J1A के अंदर कोई आइसोलेशन सॉल्वे नहीं होना चाहिए । यह आइसोलेशन सॉल्वे पैक करने के बाद ही हमें काटना पैकिंग करनी है

PACKING STD. NOT UPDATE

PACKING STD. UPDATE