

GKN SINTER METALS PVT LIMITED

WORK INSTRUCTIONS

TITLE

ISSUE DATE 10.08.2021

PAGE 1 OF 1

WORK INSTRUCTION TO PLACE
POLYTHENE BAG INSIDE BASKET

WORKS INSTRUCTIONS NO. : HtO 6 9010 WI 17 PIM A

- 1 Confirm the part number as per WIP ticket
- 2 Ensure polythene bag is placed inside basket to avoid parts contact with surface



- 3 Do not put material in basket if polythene bag not available
- 4 Confirm the part movement with polythene bag covered baskets
- 5 After visual inspection verify part for 24 hours & then pack into carton box

PREPARED BY	APPROVED BY	REVISION	Remark	REVISION DATE
RGK	RRG	A	Reviewed	17.02.2024
Engineer	Quality Incharge	Department: Plant 1 & Final Insp.		

HtO 6 9010 WI 17 PIM A