

WORK INSTRUCTION FOR INSPECTION OF ALL TYPE OF BUMP STOP

WORK INST NO SHEET NO

PART NAME / NO :- RUBBER BUSH 53BKZ00102

1 NO DEFECT-OK SAMPLE PART SHOULD BE CHECK AS PER IMAGE 2 AIRTRAP SHOULD BE FREE FROM AIRTRAP 3 RUBBER CRACK SHOULD BE FREE FROM RUBBER CRACK	Operator Inspection Report Operator Inspection Report
2 AIRTRAP SHOULD BE FREE FROM RUBBER CRACK	Inspection Report Operator Inspection
3 RUBBER CRACK SHOULD BE FREE FROM RUBBER CRACK Visual 100% Operator & In process QA	Inspection
FROM RUBBER CRACK FROM RUBBER CRACK Visual Operator & In process QA Visual	
4 UNDER CURE FROM SHORT MOULDING SHOULD BE FREE FROM SHORT MOULDING Visual 100% Operator & In process QA	Operator Inspection Report
	Operator Inspection Report
5 FLOW MARKS SHOULD BE FREE FROM FLOW MARKS Visual 100% Operator & In process QA	Operator Inspection Report
6 FLASHES SHOULD BE FREE FROM FLASHES VISUAL 100% Operator & In process QA	Operator Inspection Report
7 RUBBER SHORT MOULDING SHOULD BE FREE FROM SHORT MOULDING Visual 100% Operator & In process QA	Operator Inspection Report
8 EXCESS DEFLASHING SHOULD BE FREE FROM EXCESS DEFLASHING Visual 100% Operator & In process QA	Operator Inspection Report
KIRAN KIRAN P.L.MALANI	Į.
PREP BY CHKD BY APPD BY	