



MICROTRONICS

Opp. V.K. Height, Near City Post Office, Anguribagh, Aurangabad. Ph.: 0240 - 2340459, 6504286, Mob: 9850090407 E-mail: microtronics_ups@rediffmail.com, laxmikant@microtronics.in

Plot No.54, Gut No.99, Behind A.S. Club, Near New Mhada Colony, Waluj Mahanagar, CIDCO, Tisgaon, Aurangabad

Ref. :

Date:

22/05/2023

Safety Precaution Do's SOP

- 1. Ensure UPS is kept in 'ON' position 24×7 basis
- 2. UPS should be placed in Dust Free and clean environment.
- 3. Install proper cooling systems in UPS room or ensure proper cross ventilation for better performance of UPS and batteries.
- 4. Ensure no raptiles like mouse, lizard in UPS room.
- 5. UPS batteries should be kept in a dry and enclosed place in a rack.
- 6. Keep the UPS and battery bank away from sparks, heat source or fire.
- 7. Site should have sufficient space for maintenance of UPS and batteries.
- 8. Maintenance power plug socket is available nearer to the UPS panel.
- 9. UPS room should be protected from unauthorised entry.
- 10. All batteries should be inspected for hairline cracks.
- 11. If office is at the area where power fluctuations are high, ensure proper Servo stabliser/SPD is installed.
- 12. Earthing should be checked in due time intervals.
- 13. Get Half yearly preventive maintenance of UPS by giving proper shutdown for smooth functioning of machine.

Safety Precaution Dont's SOP

- 1. Location of the UPS should NOT be changed without the permission of manufacturer/supplier as due guidance required by trained engineer while shifting UPS.
- 2. UPS Should not be turned off without the permission of manufacturer/ Supplier as due guidance required by trained engineer while switching off the UPS.
- 3. There should NOT be water seepage near the UPS and batteries.
- 4. There should NOT be heat in the UPS and battery
- 5. UPS should NOT be kept in dusty environment.
- 6. In UPS room, Do not keep any food item, or any kind of garbage.
- 7. In case of any issue, Call authorised supplier immediately.